1. Please find the touch pad icon on the right-down corner of the Desktop. Click the right mouse button on it.
2. Select “Property of Touch-Pad”.



3. Select “ELAN” label.
4. Uncheck the “Disable when external USB pointing device plug in" option.
5. Press "Apply" to complete the set up.

