

USB Drive

System Configuration			
MB Barcode		R114 6B20354792	
Device Configuration	Manufacturer	Model No.	Spec.
	Processor	Intel Pentium4 3.2GHZ(Prescott)	FSB800MHZ
	Memory	A-DATA Vitesta M2OEL6F3G3160A1E0Z	256MB,PC2 6400
	VGA Card	MSI MS-8997 (Radeon X800 Pro)	PCI-E X16,128MB
	Lan Card	Realtek RTL8111B	
	Sound Card	Realtek ALC888	AC'97
	Hard Drive	HITACHI HDS728080PLA380	80GB
	CD-ROM	MSI MS-8216B-010	16X DVDROM,ATA33
	Floppy Drive	SAMSUNG SFD-321B	1.44MB
	Power Supply	Thermaltake PurePower	460W
	Mouse	多彩 M346	PS/2
	Keyboard	MSI MSI-101XBL	PS/2
Monitor	BENQ A770Plus	17"CRT	
SW Info	VGA BIOS	Intel Video Bios	
	VGA Driver	6.14.10.4421	As Follows
	MB Driver		(from MI31009-CD)

USB 1.1

Type	Model		Plug/Play	Restart	STR (S3)	Result
			10X	5X	5x	
Joystick	Logitech	J-ZA10	OK	OK	OK	OK
Joystick	Logitech	J-UB12	OK	OK	OK	OK
Game Pad	Logitech	G-2B-PHI	OK	OK	OK	OK
Game pad	Betop	BTP-C027	OK	OK	OK	OK
Game Mouse	清華同方	GM2(H03)	OK	OK	OK	OK
遊戲方向盤	清華同方	J11S	OK	OK	OK	OK
手寫筆	漢王	HW-ETU1	OK	OK	OK	OK
HDD	aigo	USB&1394	OK	OK	OK	OK
FDD	MITSUMI	D353FUE	OK	OK	OK	OK
	SONY	MPF82E	OK	OK	OK	OK
	IBM	FD-05PUB	OK	OK	OK	OK
Flash Memory	THUNIS	紫光文通 64MB	OK	OK	OK	OK
	Netac	加密型 II(32MB)	OK	OK	OK	OK
Keyboard	Viewsonic	VSACC27936-1G	OK	OK	OK	OK
	Viewsonic	VS10230	OK	OK	OK	OK
	MSI	MSK-1031N	OK	OK	OK	OK
	BenQ	6511-UJ	OK	OK	OK	OK
	雙飛燕	KBS-3	OK	OK	OK	OK
	Dell	SK-8135	OK	OK	OK	OK

Mouse	Dell	Sk-8115	OK	OK	OK	OK
	BenQ	M800	OK	OK	OK	OK
	Logitech	MX510	OK	OK	OK	OK
	Logitech	MX310	OK	OK	OK	OK
	Logitech	M-UV83	OK	OK	OK	OK
	Viewsonic	VS10087	OK	OK	OK	OK
	Microsoft	IntelliMouse Explorer 3.0 USB & PS/2	OK	OK	OK	OK
Wireless Keyboard/Mouse	雙飛燕	KBS-1257RP	OK	OK	OK	OK
	Viewsonic	CW2206	OK	OK	OK	OK

Type	Model		Plug/Play	Restart	STR (S3)	Result
			10X	5X	5x	
Printer	HP	Laserjet 1015	OK	OK	OK	OK
	HP	Deskjet 5652	OK	OK	OK	OK
ZIP	IOMEGA	Z100USBS	OK	OK	OK	OK
Scanner	BENQ	6678-9WM	OK	OK	OK	OK
WLAN	TP-LINK	TL-WN220M (IEEE 802.11b)	OK	OK	OK	OK
Camera	Delux	DLV-B16	OK	OK	OK	OK
Speaker	Hussar	UDA10	OK	OK	OK	OK

USB 2.0

Type	Model		Plug/Play	Restart	STR (S3)	Result
			10X	5X	5x	
HDD	BenQ	DP302 (40GB)	OK	OK	OK	OK
	IBM	TravelStar(20GB)	OK	OK	OK	OK
	LuWen	Portable HD Box	OK	OK	OK	OK
Flash Memory	aigo	迷你型 II(128MB)	OK	OK	OK	OK
	BenQ	BU202 (128MB)	OK	OK	OK	OK
	Netac	U230 (128MB)	OK	OK	OK	OK
	aigo	精銳型 128MB II 代	OK	OK	OK	OK
CD-RW	BenQ	5232W1	OK	OK	OK	OK
Combo	BenQ	TB248T	OK	OK	OK	OK
DVD-ROM	EKEPC	DV-8418AU	OK	OK	OK	OK
DVD Dual	Teclast	DWB8PUM	OK	OK	OK	OK
	Teclast	DWB16PU	OK	OK	OK	OK
WLAN	TP-LINK	TL-WN620G (IEEE 802.11g)	OK	OK	OK	OK
	ASUS	WL-167g USB WLAN Adapter	OK	OK	OK	OK