

USB Drive

USB 1.1

| Type | Model | | Plug/Play | Restart | STR (S3) | Result |
|-------------------------|-----------|--------------------------------------|-----------|---------|----------|--------|
| | | | 10X | 5X | 5x | |
| Jovstick | Logitech | J-ZA10 | OK | OK | OK | OK |
| | Logitech | J-UB12 | OK | OK | OK | OK |
| Game Pad | Logitech | G-2B-PHI | OK | OK | OK | OK |
| | Betop | BTP-C027 | OK | OK | OK | OK |
| Game Mouse | 清華同方 | GM2(H03) | OK | OK | OK | OK |
| 遊戲方向盤 | 清華同方 | J11S | OK | OK | OK | OK |
| FDD | MITSUMI | D353FUE | OK | OK | OK | OK |
| | SONY | MPF82E | OK | OK | OK | OK |
| Keyboard | Viewsonic | VSACC27936-1G | OK | OK | OK | OK |
| | Viewsonic | VS10230 | OK | OK | OK | OK |
| | MSI | MSK-1031N | OK | OK | OK | OK |
| | BenQ | 6511-UJ | OK | OK | OK | OK |
| | 雙飛燕 | KBS-3 | OK | OK | OK | OK |
| | Dell | SK-8135 | OK | OK | OK | OK |
| | Dell | SK-8115 | OK | OK | OK | OK |
| Mouse | BenQ | M800 | OK | OK | OK | OK |
| | Logitech | MX510 | OK | OK | OK | OK |
| | Logitech | MX310 | OK | OK | OK | OK |
| | Logitech | M-UV83 | OK | OK | OK | OK |
| | Viewsonic | VS10087 | OK | OK | OK | OK |
| | Microsoft | IntelliMouse Explorer 3.0 USB & PS/2 | OK | OK | OK | OK |
| | Microsoft | Wheel Mouse Optical USB & PS/2 | OK | OK | OK | OK |
| Wireless Keyboard/Mouse | 雙飛燕 | KBS-1257RP | OK | OK | OK | OK |
| | Viewsonic | CW2206 | OK | OK | OK | OK |
| Printer | Epson | EPL-6200L | OK | OK | OK | OK |
| | HP | Laserjet 1015 | OK | OK | OK | OK |
| | Canon | PIXMA iP1200 | OK | OK | OK | OK |
| ZIP | IOMEGA | Z100USBS | OK | OK | OK | OK |
| Scanner | Canon | CanoScan LiDE 25 | OK | OK | OK | OK |
| Web Cam | Delux | DLV-B16 | OK | OK | OK | OK |
| | Logitech | QuickCam Cool | OK | OK | OK | OK |
| Sound Card | Creative | X-Fi Xmod | OK | OK | OK | OK |
| Cardreader | SSK | All in 1 Card Reader | OK | OK | OK | OK |
| | 世紀飛揚 | CF-RS205 | OK | OK | OK | OK |

USB 2.0

| Type | Model | | Plug/Play | Restart | STR (S3) | Result |
|----------|--------------|-----------------------------|-----------|---------|----------|--------|
| | | | 10X | 5X | 5x | |
| HDD | BenQ | DP302 (40GB) | OK | OK | OK | OK |
| | IBM | TravelStar(20GB) | OK | OK | OK | OK |
| | LuWen | Portable HD Box | OK | OK | OK | OK |
| | BENQ | DP308 (20GB) | OK | OK | OK | OK |
| | Value Disk | US767 (40GB) | OK | OK | OK | OK |
| | Seagate | ST3250824U2-RK | OK | OK | OK | OK |
| | Thermaltake | Max4 | OK | OK | OK | OK |
| | Datastorage | K3-eSATA | OK | OK | OK | OK |
| | Datastorage | PD-eSATA | OK | OK | OK | OK |
| | Flash Memory | Kingmax | 超棒 2GB | OK | OK | OK |
| Kingston | | DataTraveler ReadyFlash 1GB | OK | OK | OK | OK |
| Netac | | U285(1GB) | OK | OK | OK | OK |

| | | | | | | |
|-----------|-----------|--------------------------------|----|----|----|----|
| | Lenovo | 智存卡 3.0(2GB) | OK | OK | OK | OK |
| | Aigo | 迷你王(精銳型 1GB II 代) | OK | OK | OK | OK |
| | Teclast | 酷閃晶彩(4GB) | OK | OK | OK | OK |
| | Apacer | AH320(8GB) | OK | OK | OK | OK |
| Web Cam | Teclast | 變形金剛(TL-T838-NDE2S) | OK | OK | OK | OK |
| | Microsoft | LifeCam VX-1000 | OK | OK | OK | OK |
| CD-RW | BenQ | 5232W1 | OK | OK | OK | OK |
| Combo | BenQ | TB248T | OK | OK | OK | OK |
| DVD Dual | Teclast | DWB16PU | OK | OK | OK | OK |
| HD DVD RW | HP | HD 100 | OK | OK | OK | OK |
| WLAN | ASUS | WL-167q USB WLAN Adapter (54M) | OK | OK | OK | OK |
| | LINKSYS | WUSB54G Ver:4 (54M) | OK | OK | OK | OK |
| | TP-LINK | TL-WN322G+ (54M) | OK | OK | OK | OK |
| | ALPHA | AFW-GU50 (54M) | OK | OK | OK | OK |