

USB Device

USB 1.1

Type	Model		Plug/Play	Restart	STR (S3)	Result	
			6X	3X	3x		
Jovstick	*	Logitech	Extreme 3D Pro Twis Handle Jovstick (J-UK17)	OK	OK	OK	OK
	*	Logitech	E-EL13	OK	OK	OK	OK
Cardreader		SSK	All in 1 Card Reader	OK	OK	OK	OK

USB 2.0

Type	Model		Plug/Play	Restart	STR (S3)	Result
			6X	3X	3x	
HDD	LACIE	Mini HUB HD(USB & 1394, 300GB)	OK	OK	OK	OK
	Datastorage	T Series(120GB)	OK	OK	OK	OK
	Founder	e 存 H1200(160GB)	OK	OK	OK	OK
	WD	My Book home Edition WD5000H1CS-00(500G)	OK	OK	OK	OK
	Seagate	FreeAgent Xtreme (1TB)	OK	OK	OK	OK
	Maxtor	Onetouch4 mini 320GB	OK	OK	OK	OK
	Seagate	FreeAgent Xtreme (1.5TB)	OK	OK	OK	OK
	STARDOM	ST5610-4S-SB2(4*750GB)	OK	OK	OK	OK
SSD	RiData	Combo SSD 16GB	OK	OK	OK	OK
Flash Drive	Teclast	酷闪晶彩(16GB)	OK	OK	OK	OK
	Eaget	CM960PRO(32GB)	OK	OK	OK	OK
	Eaget	CM960(16GB)	OK	OK	OK	OK
	Aigo	L8298	OK	OK	OK	OK
	PNY	虎年威盘	OK	OK	OK	OK
	Sandisk	SDCZ8-032GRB(32GB)	OK	OK	OK	OK
Web Cam	Logitech	QuickCam Pro For Notebooks (V-UBU48)	OK	OK	OK	OK
	Microsoft	LifeCam VX-6000	OK	OK	OK	OK
ODD	PLEXTOR	PX-810UF	OK	OK	OK	OK
	LACIE	d2 DVD ± RW	OK	OK	OK	OK
	Lacie	8X d2 Blu-Ray USB2&FWU	OK	OK	OK	OK
	Buffalo	BUF-BR-816SU2(B)	OK	OK	OK	OK
WLAN	ALPHA	AFW-GU50 (54M)	OK	OK	OK	OK
	D-link	DWA-140 (54M)	OK	OK	OK	OK
	LINKSYS	WUSB54G Ver:4 (54M)	OK	OK	OK	OK
	TP-LINK	TL-WN322G+ (54M)	OK	OK	OK	OK
	BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
TV Card	10Moons	UAD-TH200	OK	OK	OK	OK
Printer	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
Scanner	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
	EPSON	Perfection V10 (J231A)	OK	OK	OK	OK
USB HUB	D-Link	DUB-H7	OK	OK	OK	OK

USB 3.0

Type	Model		Plug/Play	Restart	STR (S3)	Result
			6X	3X	3x	
HDD	BUFFALO	HD-H1.0TU3(1TB)	OK	OK	OK	OK
ODD	RATOC	RS-EC5-U3	OK	OK	OK	OK