

# USB Device

## USB 1.1

Type	Model		Plug/Play 6X	Restart 3X	STR (S3) 3x	Result
Joystick	Logitech	Extreme 3D Pro Twis Handle Joystick (J-UK17)	OK	OK	OK	OK
	Logitech	ChillStream (G-UH21)	OK	OK	OK	OK
	Logitech	E-EL13	OK	OK	OK	OK
	Microsoft	XBOX 360™ Wireless Controller	OK	OK	OK	OK
FDD	MITSUMI	D353FUE	OK	OK	OK	OK
	SONY	MPF82E	OK	OK	OK	OK
Keyboard	Logitech	Wave Keyboard (Y-UV90)	OK	OK	OK	OK
	Logitech	illuminated USB Keyboard (Y-UY95)	OK	OK	OK	OK
	Microsoft	SideWinder X4 Keyboard(1421)	OK	OK	OK	OK
Mouse	Logitech	G1 Optical Mouse (M-BP82)	OK	OK	OK	OK
	Logitech	光電獵貂 1000 (M-BZ96C)	OK	OK	OK	OK
	Microsoft	光學精靈鯊 500 V2.0	OK	OK	OK	OK
	Microsoft	SideWinder X3 Mouse	OK	OK	OK	OK
Wireless Keyboard/Mouse	A4TECH	KBS-1257RP	OK	OK	OK	OK
	Logitech	Cordless Desktop LX310 Laser (PS2+USB)	OK	OK	OK	OK
	Logitech	Cordless Desktop EX110 (PS2+USB)	OK	OK	OK	OK
	Microsoft	Wireless Desktop 6000	OK	OK	OK	OK
Printer	Canon	PIXMA iP1200	OK	OK	OK	OK
	Epson	EPL-6200L	OK	OK	OK	OK
	EPSON	Stylus CX5500	OK	OK	OK	OK
Scanner	EPSON	Stylus CX5500	OK	OK	OK	OK
	Canon	CanoScan LiDE 25	OK	OK	OK	OK
	HP	Scanjet G2410 Flatbed Scanner (GRLYB-0209)	OK	OK	OK	OK
Sound Card	Creative	X-Fi Xmod	OK	OK	OK	OK
Speaker	Logitech	V10 Notebook Speakers (S-0194B)	OK	OK	OK	OK
Cardreader	SSK	All in 1 Card Reader	OK	OK	OK	OK

## USB 2.0

Type	Model		Plug/Play 6X	Restart 3X	STR (S3) 3x	Result
HDD	LACIE	Mini HUB HD(USB & 1394, 300GB)	OK	OK	OK	OK
	Datastorage	T Series(120GB)	OK	OK	OK	OK
	Founder	e 存 H1200(160GB)	OK	OK	OK	OK
	WD	My Book home Edition WD5000H1CS-00(500G) (USB2.0/eSATA/1394)	OK	OK	OK	OK
	Seagate	FreeAgent Xtreme (1TB)	OK	OK	OK	OK
	Maxtor	Onetouch4 mini 320GB	OK	OK	OK	OK
	Seagate	FreeAgent Xtreme (1.5TB)	OK	OK	OK	OK
	STARDOM	ST5610-4S-SB2(4*750GB)	OK	OK	OK	OK
SSD	RiData	Combo SSD 16GB	OK	OK	OK	OK
Flash Drive	Apacer	AH328(16GB)	OK	OK	OK	OK
	Teclast	酷閃晶彩(16GB)	OK	OK	OK	OK
	Eaget	CM960PRO(32GB)	OK	OK	OK	OK
	Eaget	CM960(16GB)	OK	OK	OK	OK
	Aigo	L8298	OK	OK	OK	OK
	Sandisk	SDCZ8-032GRB(32GB)	OK	OK	OK	OK
ODD	PLEXTOR	PX-810UF	OK	OK	OK	OK
	LACIE	d2 DVD ± RW	OK	OK	OK	OK
	Lacie	8X d2 Blu-Ray USB2&FWU	OK	OK	OK	OK
	Buffalo	BUF-BR-816SU2(B)	OK	OK	OK	OK
WLAN	ALPHA	AFW-GU50 (54M)	OK	OK	OK	OK
	D-link	DWA-140 (54M)	OK	OK	OK	OK
	LINKSYS	WUSB54G Ver:4 (54M)	OK	OK	OK	OK
	TP-LINK	TL-WN322G+ (54M)	OK	OK	OK	OK
	BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
	10Moons	UAD-TH200	OK	OK	OK	OK
TV Card	MSI	DIGIVOX A/D IV	OK	OK	OK	OK
Printer	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
Scanner	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
	EPSON	Perfection V10 (J231A)	OK	OK	OK	OK

USB HUB	D-Link	DUB-H7	OK	OK	OK	OK
Cardreader	Apacer	AM401	OK	OK	OK	OK
	Transcend	TS-RDP7K	OK	OK	OK	OK

## USB 3.0

Type	Model		Plug/Play 6X	Restart 3X	STR (S3) 3x	Result
HDD	BUFFALO	HD-H1.0TU3(1TB)	OK	OK	OK	OK
	WD	My book 3.0 WDBABP0010HCH (1TB)	OK	OK	OK	OK
	Seagate	Free Agent Goflex(1TB)	OK	OK	OK	OK
	Snake	U-3000 (640GB)	OK	OK	OK	OK
SSD	ADATA	NOBILITY N004((64GB)	OK	OK	OK	OK
	OCZ	OCZSSDU3-1ENY64G (64GB)	OK	OK	OK	OK
ODD	RATOC	RS-EC5-U3	OK	OK	OK	OK
Flash Drive	RiDATA	HD5(32GB)	OK	OK	OK	OK

## USB 3.0 Connector

### USB 1.1 Device

Type	Model		Plug/Play 10X	Restart 5X	STR (S3) 5x	Result
Joystick	Microsoft	XBOX Wireless Controller	OK	OK	OK	OK
Keyboard	Logitech	illuminated USB Keyboard (Y-U95)	OK	OK	OK	OK
Mouse	Microsoft	SideWinder X3 Mouse	OK	OK	OK	OK

### USB 2.0 Device

Type	Model		Plug/Play 10X	Restart 5X	STR (S3) 5x	Result
HDD	STARDOM	ST5610-4S-SB2(4*750GB)	OK	OK	OK	OK
SSD	RiData	Combo SSD 16GB	OK	OK	OK	OK
Flash Drive	Eaget	CM960PRO(32GB)	OK	OK	OK	OK
ODD	Buffalo	BUF-BR-816SU2(B)	OK	OK	OK	OK
WLAN	BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
Printer	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
Scanner	EPSON	Perfection V10 (J231A)	OK	OK	OK	OK

### USB 3.0 Device

Type	Model		Plug/Play 6X	Restart 3X	STR (S3) 3x	Result
HDD	BUFFALO	HD-H1.0TU3(1TB)	OK	OK	OK	OK
	Seagate	Free Agent Goflex(1TB)	OK	OK	OK	OK
	Snake	U-3000 (640GB)	OK	OK	OK	OK
SSD	ADATA	NOBILITY N004((64GB)	OK	OK	OK	OK
	OCZ	OCZSSDU3-1ENY64G (64GB)	OK	OK	OK	OK
ODD	RATOC	RS-EC5-U3	OK	OK	OK	OK
Flash Drive	RiDATA	HD5(32GB)	OK	OK	OK	OK