

USB Device

USB 1.1

Type	Model	Plug/Play	Restart	STR (S3)	Result	
		6X	3X	3x		
Jovstick	Logitech	Extreme 3D Pro Twis Handle Jovstick (J-UK17)	OK	OK	OK	OK
	Logitech	ChillStream (G-UH21)	OK	OK	OK	OK
	Logitech	E-EL13	OK	OK	OK	OK
FDD	MITSUMI	D353FUE	OK	OK	OK	OK
	SONY	MPF82E	OK	OK	OK	OK
Keyboard	Logitech	Wave Keyboard (Y-UV90)	OK	OK	OK	OK
	Logitech	illuminated USB Keyboard (Y-UJ95)	OK	OK	OK	OK
	Microsoft	SideWinder X4 Keyboard(1421)	OK	OK	OK	OK
Mouse	Logitech	光電獵貂 1000 (M-BZ96C)	OK	OK	OK	OK
	Microsoft	光學精靈鯊 500 V2.0	OK	OK	OK	OK
	Microsoft	SideWinder X3 Mouse	OK	OK	OK	OK
Wireless Keyboard/Mouse	A4TECH	KBS-1257RP	OK	OK	OK	OK
	Logitech	Cordless Desktop LX310 Laser (PS2+USB)	OK	OK	OK	OK
	Logitech	Cordless Desktop EX110 (PS2+USB)	OK	OK	OK	OK
	Microsoft	Wireless Desktop 6000	OK	OK	OK	OK
Printer	Canon	PIXMA iP1200	OK	OK	OK	OK
	Epson	EPL-6200L	OK	OK	OK	OK
	EPSON	Stylus CX5500	OK	OK	OK	OK
Scanner	EPSON	Stylus CX5500	OK	OK	OK	OK
	Canon	CanoScan LiDE 25	OK	OK	OK	OK
	HP	Scanjet G2410 Flatbed Scanner (GRLYB-0209)	OK	OK	OK	OK
Web Cam	Logitech	QuickCam Cool	OK	OK	OK	OK
	Logitech	Quickcam Connect (V-UBQ42)	OK	OK	OK	OK
Speaker	Logitech	V10 Notebook Speakers (S-0194B)	OK	OK	OK	OK
Cardreader	SSK	All in 1 Card Reader	OK	OK	OK	OK

USB 2.0

Type	Model	Plug/Play	Restart	STR (S3)	Result	
		6X	3X	3x		
HDD	LACIE	Mini HUB HD(USB & 1394. 300GB)	OK	OK	OK	OK
	Datastorage	T Series(120GB)	OK	OK	OK	OK
	Founder	e 存 H1200(160GB)	OK	OK	OK	OK
	Seagate	FreeAgent Xtreme (1TB)	OK	OK	OK	OK
	Pqi	S512(32GB)	OK	OK	OK	OK
SSD	RiData	Combo SSD 16GB	OK	OK	OK	OK
Flash Drive	Apacer	AH328(16GB)	OK	OK	OK	OK
	Teclast	酷閃晶彩(16GB)	OK	OK	OK	OK
	Eaget	CM960(16GB)	OK	OK	OK	OK
Web Cam	Logitech	QuickCam Pro For Notebooks (V-UBU48)	OK	OK	OK	OK
ODD	PLEXTOR	PX-810UF	OK	OK	OK	OK
WLAN	ALPHA	AFW-GU50 (54M)	OK	OK	OK	OK
	D-link	DWA-140 (54M)	OK	OK	OK	OK
	LINKSYS	WUSB54G Ver:4 (54M)	OK	OK	OK	OK
	TP-LINK	TL-WN322G+ (54M)	OK	OK	OK	OK
	BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
TV Card	MSI	DIGIVOX A/D IV	OK	OK	OK	OK
Printer	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
Scanner	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
	EPSON	Perfection V10 (J231A)	OK	OK	OK	OK
USB HUB	D-Link	DUB-H7	OK	OK	OK	OK

Cardreader	Apacer	AM401	OK	OK	OK	OK
	Transcend	TS-RDP7K	OK	OK	OK	OK

USB 3.0

Type	Model	Plug/Play 6X	Restart 3X	STR (S3) 3x	Result	
						SSD
ODD	RATOC	RS-EC5-U3	OK	OK	OK	OK
Flash Drive	Kingston	DTU30/16GB	OK	OK	OK	OK

USB 3.0 Card

Model		Speed Check	Insert USB 3.0 HDD	Copy & Compare File	Result
BUFFALO	ICF-PCIE2U3	OK	OK	OK	OK