

# USB Device

Product name: H61M-P31 (G3)

BIOS ver.: 2.0

## Keyboard & Mouse EFI BIOS Test:

Type	Model		Plug/Play 3X	Function	Result		
Keyboard	Cherry	G80-3000(USB1.1+PS/2)	OK	OK	OK		
	i-rocks	KR-6431	OK	OK	OK		
	Logitech	illuminated USB Keyboard (Y-UY95)		OK	OK	OK	
		Wireless Solar Keyboard K750		OK	OK	OK	
		G15(Y-UW92)		OK	OK	OK	
		G19(Y-U0005)		OK	OK	OK	
		G510(Y-U0010)		OK	OK	OK	
	Microsoft	Comfort Curve Keyboard 3000		OK	OK	OK	
		SideWinder X4 Keyboard(1421)		OK	OK	OK	
	RAZER	Lycosa		OK	OK	OK	
	Tt esports	Challenger Pro		OK	OK	OK	
		Challenger(KB-CHL002)		OK	OK	OK	
Mouse	CMSTORM	Sentinel Z3RO-G(SGM-60001-GLLW1-GP)		OK	OK	OK	
		Spawn(SGM-2000-ML0N1)		OK	OK	OK	
	Cyborg	R.A.T3		OK	OK	OK	
		R.A.T5		OK	OK	OK	
		R.A.T7		OK	OK	OK	
		R.A.T9(Wireless)		OK	OK	OK	
		Cyborg V.3 Mouse		OK	OK	OK	
	Logitech	G300		OK	OK	OK	
		G400		OK	OK	OK	
		G500		OK	OK	OK	
		G5(M-UAH113A)		OK	OK	OK	
		G700(Wireless)		OK	OK	OK	
		G9X		OK	OK	OK	
		M125		OK	OK	OK	
		M950(Wireless)		OK	OK	OK	
		MX518(Y-U0010)		OK	OK	OK	
	Mouse	Microsoft	Arc Touch USB Mouse		OK	OK	OK
			SideWinder X3 Mouse		OK	OK	OK
			SideWinder X5 Mouse		OK	OK	OK
			SideWinder X8 Wireless Mouse		OK	OK	OK
Touch Mouse			OK	OK	OK		
MSI		Wireless Gesture		OK	OK	OK	
Ozone		Radon 3k (OZRADON3K)		OK	OK	OK	
		Radon 5k (OZRADON5K)		OK	OK	OK	
Razer		Abyssus(RZ01-0036)		OK	OK	OK	
		Copperhead (RZ01-050100)		OK	OK	OK	
		Deathadder Black Edition (RZ01-0015)		OK	OK	OK	
		Deathadder Left-hand(RZ01-0015)		OK	OK	OK	
		DeathAdder (RZ01-0015)		OK	OK	OK	
		Imperator (RZ01-0035)		OK	OK	OK	
		Imperator 4G (RZ01-0035)		OK	OK	OK	
		Lachesis(RZ01-0017)		OK	OK	OK	
		Mamba 4G(RC30-001206) (Wireless)		OK	OK	OK	
		Naga epic(RC30-005101)		OK	OK	OK	
		Orochi Bluetooth Mobile		OK	OK	OK	
		Spectre(RZ01-0043)		OK	OK	OK	
Tron (RZ01-0052)		OK	OK	OK			

	Roccat	KONE+(ROC-11-800-AS)	OK	OK	OK
		PYRA(ROC-11-300-AS)	OK	OK	OK
		PYRA(ROC-11-510-AS)	OK	OK	OK
	Steelseries	IKARI Laser	OK	OK	OK
		IKARI Optical	OK	OK	OK
		KINZU Optical	OK	OK	OK
		XAI Laser	OK	OK	OK
	Tt eSPorts	AZURUES Mini	OK	OK	OK
		Black Element(MO-BLE001DT)	OK	OK	OK
		Black(MO-BLK002DT)	OK	OK	OK
Wglobal	ConfI(TM-5)	OK	OK	OK	
Wireless Keyboard	Logitech	Cordless Desktop LX310 Laser (PS2+USB)	OK	OK	OK
	Logitech	Cordless Desktop MX5500 Bluetooth	OK	OK	OK
And Mouse	Microsoft	Wireless Desktop 6000	OK	OK	OK

## USB 1.1

Type	Model		Plug/Play	Restart	STR (S3)	Result
			3X	3X	3x	
FDD	MITSUMI	D353FUE	OK	OK	OK	OK
	SONY	MPF82E	OK	OK	OK	OK
Gamingboard	Logitech	G13	OK	OK	OK	OK
Joystick	Logitech	Extreme 3D Pro Twis Handle Joystick (J-UK17)	OK	OK	OK	OK
	Microsoft	XBOX 360™ Wireless Controller	OK	OK	OK	OK
	Logitech	Rumble Gamepad F510	OK	OK	OK	OK
Keyboard	Cherry	G80-3000(USB1.1+PS/2)	OK	OK	OK	OK
	i-rocks	KR-6431	OK	OK	OK	OK
	Logitech	illuminated USB Keyboard (Y-UJ95)	OK	OK	OK	OK
		Wireless Solar Keyboard K750	OK	OK	OK	OK
		G19(Y-U0005)	OK	OK	OK	OK
	Microsoft	Comfort Curve Keyboard 3000	OK	OK	OK	OK
	RAZER	Lycosa	OK	OK	OK	OK
Challenger(KB-CHL002)		OK	OK	OK	OK	
Mouse	CMSTORM	Inferno(SGM-4000-KLLN1-GP)	OK	OK	OK	OK
		Sentinel Z3RO-G(SGM-60001-GLLW1-GP)	OK	OK	OK	OK
	Cyborg	R.A.T9(Wireless)	OK	OK	OK	OK
		Cyborg V.3 Mouse	OK	OK	OK	OK
	Logitech	M125	OK	OK	OK	OK
		G500	OK	OK	OK	OK
		G700(Wireless)	OK	OK	OK	OK
		G9X	OK	OK	OK	OK
	Microsoft	Arc Touch USB Mouse	OK	OK	OK	OK
		SideWinder X5 Mouse	OK	OK	OK	OK
		SideWinder X8 Wireless Mouse	OK	OK	OK	OK
		Touch Mouse	OK	OK	OK	OK
		Wireless Mouse 5000	OK	OK	OK	OK
	MSI	Wireless Gesture	OK	OK	OK	OK
	Nova	Slider X600	OK	OK	OK	OK
	Ozone	Radon 5k (OZRADON5K)	OK	OK	OK	OK
	RAZER	Abyssus(RZ01-0036)	OK	OK	OK	OK
		Deathadder Black Edition (RZ01-0015)	OK	OK	OK	OK
		Imperator 4G (RZ01-0035)	OK	OK	OK	OK
		Lachesis(RZ01-0017)	OK	OK	OK	OK
		Mamba 4G(RC30-001206) (Wireless)	OK	OK	OK	OK
		Naga epic(RC30-005101)	OK	OK	OK	OK
	ROCCAT	KOVA(ROC-11-200-AS)	OK	OK	OK	OK
		PYRA(ROC-11-510-AS)	OK	OK	OK	OK

	Steelseries	IKARI Laser	OK	OK	OK	OK
		XAI Laser	OK	OK	OK	OK
	Ttesport	AZURUES Mini	OK	OK	OK	OK
		Black Element(MO-BLE001DT)	OK	OK	OK	OK
	Wglobal	Confi(TM-5)	OK	OK	OK	OK
Wireless Keyboard/Mouse	Logitech	Cordless Desktop MX5500 Bluetooth	OK	OK	OK	OK
Printer	EPSON	Stylus CX5500	OK	OK	OK	OK
Scanner	EPSON	Stylus CX5500	OK	OK	OK	OK
	HP	Scanjet G2410 Flatbed Scanner (GRLYB-0209)	OK	OK	OK	OK
Speaker	Logitech	V10 Notebook Speakers (S-0194B)	OK	OK	OK	OK
	Logitech	Laptop Speaker Z305	OK	OK	OK	OK

## USB 2.0

Type	Model		Plug/Play	Restart	STR (S3)	Result
			3X	3X	3x	
HDD	STARDOM	ST5610-4S-SB2(4*750GB)	OK	OK	OK	OK
Flash Drive	Apacer	AH328(16GB)	OK	OK	OK	OK
	Sandisk	SDCZ8-032GRB(32GB)	OK	OK	OK	OK
	Kingston	DTR500/16GB	OK	OK	OK	OK
	Ridata	Mini CUBE 16GB	OK	OK	OK	OK
Web Cam	Logitech	C210	OK	OK	OK	OK
	Microsoft	LifeCam Studio	OK	OK	OK	OK
ODD	Plextor	PX-B120U	OK	OK	OK	OK
	Lacie	8X d2 Blu-Ray USB2&FWU	OK	OK	OK	OK
	Buffalo	BR-X816U2	OK	OK	OK	OK
	Pioneer	DVR-XD10T	OK	OK	OK	OK
WLAN	D-LINK	DWA-140 (54M)	OK	OK	OK	OK
	BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
TV Card	AverMedia	A850 DVB-T	OK	OK	OK	OK
	MSI	DIGIVOX A/D IV	OK	OK	OK	OK
Printer	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
Scanner	SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
	EPSON	Perfection V10 (J231A)	OK	OK	OK	OK
	EPSON	PERFECTION V330 PHOTO	OK	OK	OK	OK
USB HUB	D-Link	DUB-H7	OK	OK	OK	OK
	Transcend	TS-RDP7K	OK	OK	OK	OK
Cardreader	Apacer	AM401	OK	OK	OK	OK
	Transcend	TS-RDP7K	OK	OK	OK	OK