

# USB Device

Product name: 760GA-P43 (FX)

BIOS ver.: 1.0

## USB 2.0

Vendor	Model	Plug/Play 3X	Restart 3X	STR (S3) 3X	Result
MITSUMI	D353FUE	OK	OK	OK	OK
Logitech	G13	OK	OK	OK	OK
Microsoft	XBOX 360™ Wireless Controller	OK	OK	OK	OK
Logitech	Rumble Gamepad F510	OK	OK	OK	OK
Cherry	G80-3000(USB1.1+PS/2)	OK	OK	OK	OK
i-rocks	KR-6431	OK	OK	OK	OK
Logitech	illuminated USB Keyboard (Y-UY95)	OK	OK	OK	OK
Logitech	Wireless Solar Keyboard K750	OK	OK	OK	OK
Logitech	G19(Y-U0005)	OK	OK	OK	OK
Microsoft	Comfort Curve Keyboard 3000	OK	OK	OK	OK
RAZER	Lycosa	OK	OK	OK	OK
Ttesport	MEKA G1(KB-MEG051)	OK	OK	OK	OK
Ttesport	Challenger(KB-CHL002)	OK	OK	OK	OK
CMSTORM	Inferno(SGM-4000-KLLN1-GP)	OK	OK	OK	OK
CMSTORM	Sentinel Z3RO-G(SGM-60001-GLLW1-GP)	OK	OK	OK	OK
Cyborg	R.A.T9(Wireless)	OK	OK	OK	OK
Cyborg	Cyborg V.3 Mouse	OK	OK	OK	OK
Logitech	M125	OK	OK	OK	OK
Logitech	G500	OK	OK	OK	OK
Logitech	G700(Wireless)	OK	OK	OK	OK
Logitech	G9X	OK	OK	OK	OK
Microsoft	Arc Touch USB Mouse	OK	OK	OK	OK
Microsoft	SideWinder X5 Mouse	OK	OK	OK	OK
Microsoft	SideWinder X8 Wireless Mouse	OK	OK	OK	OK
Microsoft	Touch Mouse	OK	OK	OK	OK
Microsoft	Wireless Mouse 5000	OK	OK	OK	OK
MSI	Wireless Gesture	OK	OK	OK	OK
Nova	Slider X600	OK	OK	OK	OK
Ozone	Radon 5k (OZRADON5K)	OK	OK	OK	OK
RAZER	Abbyssus(RZ01-0036)	OK	OK	OK	OK
RAZER	Deathadder Black Edition (RZ01-0015)	OK	OK	OK	OK
RAZER	Imperator 4G (RZ01-0035)	OK	OK	OK	OK
RAZER	Lachesis(RZ01-0017)	OK	OK	OK	OK
RAZER	Mamba 4G(RC30-001206) (Wireless)	OK	OK	OK	OK
RAZER	Naga epic(RC30-005101)	OK	OK	OK	OK
ROCCAT	KOVA(ROC-11-200-AS)	OK	OK	OK	OK
ROCCAT	PYRA(ROC-11-510-AS)	OK	OK	OK	OK
Steelseries	IKARI Laser	OK	OK	OK	OK
Steelseries	XAI Laser	OK	OK	OK	OK
Ttesport	AZURUES Mini	OK	OK	OK	OK
Ttesport	Black Element(MO-BLE001DT)	OK	OK	OK	OK
Wglobal	Confii(TM-5)	OK	OK	OK	OK
Logitech	Cordless Desktop MX5500 Bluetooth	OK	OK	OK	OK
EPSON	Stylus CX5500	OK	OK	OK	OK
EPSON	Stylus CX5500	OK	OK	OK	OK
HP	Scanjet G2410 Flatbed Scanner (GRLYB-0209)	OK	OK	OK	OK
Logitech	V10 Notebook Speakers (S-0194B)	OK	OK	OK	OK
Logitech	Laptop Speaker Z305	OK	OK	OK	OK
STARDOM	ST5610-4S-SB2(4*750GB)	OK	OK	OK	OK
Apacer	AH328(16GB)	OK	OK	OK	OK

Sandisk	SDCZ8-032GRB(32GB)	OK	OK	OK	OK
Ridata	Mini CUBE 16GB	OK	OK	OK	OK
Logitech	C210	OK	OK	OK	OK
Microsoft	LifeCam Studio	OK	OK	OK	OK
Plextor	PX-B120U	OK	OK	OK	OK
Buffalo	BR-X816U2	OK	OK	OK	OK
Pioneer	DVR-XD10T	OK	OK	OK	OK
D-LINK	DWA-140 (54M)	OK	OK	OK	OK
BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
MSI	DIGIVOX A/D IV	OK	OK	OK	OK
SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
EPSON	Perfection V10 (J231A)	OK	OK	OK	OK
EPSON	PERFECTION V330 PHOTO	OK	OK	OK	OK
D-Link	DUB-H7	OK	OK	OK	OK
Transcend	TS-RDP7K	OK	OK	OK	OK
Apacer	AM401	OK	OK	OK	OK
Transcend	TS-RDP7K	OK	OK	OK	OK

### KB&MS in EFI BIOS ( USB2.0 )

Vendor	Model	Plug/Play 3X	Function	Result
Cherry	G80-3000(USB1.1+PS/2)	OK	OK	OK
i-rocks	KR-6431	OK	OK	OK
Logitech	illuminated USB Keyboard (Y-UY95)	OK	OK	OK
Logitech	Wireless Solar Keyboard K750	OK	OK	OK
Logitech	G15(Y-UW92)	OK	OK	OK
Logitech	G19(Y-U0005)	OK	OK	OK
Logitech	G510(Y-U0010)	OK	OK	OK
Microsoft	Comfort Curve Keyboard 3000	OK	OK	OK
Microsoft	SideWinder X4 Keyboard(1421)	OK	OK	OK
RAZER	Lycosa	OK	OK	OK
Tt esports	Challenger Pro	OK	OK	OK
Tt esports	MEKA G1(KB-MEG051)	OK	OK	OK
Tt esports	Challenger(KB-CHL002)	OK	OK	OK
Logitech	Cordless Desktop LX310 Laser (PS2+USB)	OK	OK	OK
Logitech	Cordless Desktop MX5500 Bluetooth	OK	OK	OK
Microsoft	Wireless Desktop 6000	OK	OK	OK

### USB3.0

Vendor	Model	Plug/Play 3X	Restart 3X	STR (S3) 3X	Result
MITSUMI	D353FUE	OK	OK	OK	OK
Logitech	G13	OK	OK	OK	OK
Microsoft	XBOX 360™ Wireless Controller	OK	OK	OK	OK
Logitech	Rumble Gamepad F510	OK	OK	OK	OK
Cherry	G80-3000(USB1.1+PS/2)	OK	OK	OK	OK
i-rocks	KR-6431	OK	OK	OK	OK
Logitech	illuminated USB Keyboard (Y-UY95)	OK	OK	OK	OK
Logitech	Wireless Solar Keyboard K750	OK	OK	OK	OK
Logitech	G19(Y-U0005)	OK	OK	OK	OK
Microsoft	Comfort Curve Keyboard 3000	OK	OK	OK	OK
RAZER	Lycosa	OK	OK	OK	OK
Ttesport	MEKA G1(KB-MEG051)	OK	OK	OK	OK
Ttesport	Challenger(KB-CHL002)	OK	OK	OK	OK

CMSTORM	Inferno(SGM-4000-KLLN1-GP)	OK	OK	OK	OK
CMSTORM	Sentinel Z3RO-G(SGM-60001-GLLW1-GP)	OK	OK	OK	OK
Cyborg	R.A.T9(Wireless)	OK	OK	OK	OK
Cyborg	Cyborg V.3 Mouse	OK	OK	OK	OK
Logitech	M125	OK	OK	OK	OK
Logitech	G500	OK	OK	OK	OK
Logitech	G700(Wireless)	OK	OK	OK	OK
Logitech	G9X	OK	OK	OK	OK
Microsoft	Arc Touch USB Mouse	OK	OK	OK	OK
Microsoft	SideWinder X5 Mouse	OK	OK	OK	OK
Microsoft	SideWinder X8 Wireless Mouse	OK	OK	OK	OK
Microsoft	Touch Mouse	OK	OK	OK	OK
Microsoft	Wireless Mouse 5000	OK	OK	OK	OK
MSI	Wireless Gesture	OK	OK	OK	OK
Nova	Slider X600	OK	OK	OK	OK
Ozone	Radon 5k (OZRADON5K)	OK	OK	OK	OK
RAZER	Abyssus(RZ01-0036)	OK	OK	OK	OK
RAZER	Deathadder Black Edition (RZ01-0015)	OK	OK	OK	OK
RAZER	Imperator 4G (RZ01-0035)	OK	OK	OK	OK
RAZER	Lachesis(RZ01-0017)	OK	OK	OK	OK
RAZER	Mamba 4G(RC30-001206) (Wireless)	OK	OK	OK	OK
RAZER	Naqa epic(RC30-005101)	OK	OK	OK	OK
ROCCAT	KOVA(ROC-11-200-AS)	OK	OK	OK	OK
ROCCAT	PYRA(ROC-11-510-AS)	OK	OK	OK	OK
Steelseries	IKARI Laser	OK	OK	OK	OK
Steelseries	XAI Laser	OK	OK	OK	OK
Ttesport	AZURUES Mini	OK	OK	OK	OK
Ttesport	Black Element(MO-BLE001DT)	OK	OK	OK	OK
Wglobal	Confii(TM-5)	OK	OK	OK	OK
Logitech	Cordless Desktop MX5500 Bluetooth	OK	OK	OK	OK
EPSON	Stylus CX5500	OK	OK	OK	OK
EPSON	Stylus CX5500	OK	OK	OK	OK
HP	Scanjet G2410 Flatbed Scanner (GRLYB-0209)	OK	OK	OK	OK
Logitech	V10 Notebook Speakers (S-0194B)	OK	OK	OK	OK
Logitech	Laptop Speaker Z305	OK	OK	OK	OK
Buffalo	HD-LBU2(1.0TB)	OK	OK	OK	OK
STARDOM	ST5610-4S-SB2(4*750GB)	OK	OK	OK	OK
Apacer	AH328(16GB)	OK	OK	OK	OK
Sandisk	SDCZ8-032GRB(32GB)	OK	OK	OK	OK
Kingston	DTR500/16GB	OK	OK	OK	OK
Ridata	Mini CUBE 16GB	OK	OK	OK	OK
Logitech	C210	OK	OK	OK	OK
Microsoft	LifeCam Studio	OK	OK	OK	OK
Plextor	PX-B120U	OK	OK	OK	OK
Lacie	8X d2 Blu-Ray USB2&FWU	OK	OK	OK	OK
Buffalo	BR-X816U2	OK	OK	OK	OK
Pioneer	DVR-XD10T	OK	OK	OK	OK
D-LINK	DWA-140 (54M)	OK	OK	OK	OK
BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
AverMedia	A850 DVB-T	OK	OK	OK	OK
MSI	DIGIVOX A/D IV	OK	OK	OK	OK
SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
SAMSUNG	Laser MFP SCX-4300	OK	OK	OK	OK
EPSON	Perfection V10 (J231A)	OK	OK	OK	OK
EPSON	PERFECTION V330 PHOTO	OK	OK	OK	OK
D-Link	DUB-H7	OK	OK	OK	OK
Transcend	TS-RDP7K	OK	OK	OK	OK

Apacer	AM401	OK	OK	OK	OK
Transcend	TS-RDP7K	OK	OK	OK	OK
ADATA	Nobility NH01(750GB)	OK	OK	OK	OK
ADATA	Nobility NH03(2TB)	OK	OK	OK	OK
BUFFALO	HD-H1.0TU3(1TB)	OK	OK	OK	OK
Cyberslim	S1-DS3 TURBO	OK	OK	OK	OK
Freecom	Hard Drive XS 3.0 1TB	OK	OK	OK	OK
Freecom	Mobile Drive Classic III 1TB	OK	OK	OK	OK
IOMEGA	eGo Portable Hard Drive(RPHD-UG3) 500GB	OK	OK	OK	OK
IOMEGA	eGo Desktop Hard Drive(RDHD-U23) 3TB	OK	OK	OK	OK
PQI	H566(640GB)	OK	OK	OK	OK
sharkoon	DriveLink USB3.0	OK	OK	OK	OK
Snake	U-3000 (640GB)	OK	OK	OK	OK
Transcend	TS2TSJ35T3(2TB)	OK	OK	OK	OK
WD	My book 3.0 WDBABP0010HCH (1TB)	OK	OK	OK	OK
WD	My Passport Essential SE(1TB)	OK	OK	OK	OK
Hitachi	TOURO MOBILE PRO(500GB)	OK	OK	OK	OK
Hitachi	TOURO DESK DX3(4TB)	OK	OK	OK	OK
Lacie	Hub4 USB 3.0 SH402	OK	OK	OK	OK
IOMEGA	SSD Flash External Drive 128GB	OK	OK	OK	OK
Kingston	SHX100U3/64GB	OK	OK	OK	OK
RATOC	RS-EC5-U3	OK	OK	OK	OK
Buffalo	BR3D-12U3	OK	OK	OK	OK
ADATA	Nobility N005(64GB)	OK	OK	OK	OK
Kingston	DTU30/16GB	OK	OK	OK	OK
PQI	Cool Driver U339V(32GB)	OK	OK	OK	OK
Transcend	TS32GJF700(32GB)	OK	OK	OK	OK
Buffalo	BSCRA51U3BK	OK	OK	OK	OK
Silicon power	SPC39V1W	OK	OK	OK	OK

### KB&MS in EFI BIOS ( USB3.0 )

Vendor	Model	Plug/Play 3X	Function	Result
i-rocks	KR-6431	OK	OK	OK
Logitech	illuminated USB Keyboard (Y-UY95)	OK	OK	OK
Logitech	Wireless Solar Keyboard K750	OK	OK	OK
Logitech	G15(Y-UW92)	OK	OK	OK
Logitech	G19(Y-U0005)	OK	OK	OK
Logitech	G510(Y-U0010)	OK	OK	OK
Microsoft	Comfort Curve Keyboard 3000	OK	OK	OK
Microsoft	SideWinder X4 Keyboard(1421)	OK	OK	OK
RAZER	Lycosa	OK	OK	OK
Tt esports	Challenger Pro	OK	OK	OK
Tt esports	MEKA G1(KB-MEG051)	OK	OK	OK
Tt esports	Challenger(KB-CHL002)	OK	OK	OK
Logitech	Cordless Desktop LX310 Laser (PS2+USB)	OK	OK	OK
Logitech	Cordless Desktop MX5500 Bluetooth	OK	OK	OK
Microsoft	Wireless Desktop 6000	OK	OK	OK