

FAQ No. 01507**Space key assembly guide**

Affected Model: GS/GT/GE series



Q: What if I disassemble the space key, and how should I assemble it?

A: Please refer to following guide.

There are 2 hooks on the 2 sockets (left and right) under the space bar.



UP is the space bar component you disassembled, when you assemble it, please align the socket with the hook.



The easier way to assemble space bar is starting from one side to the other side.
Below picture is pressing the space key from right corner.

