


## Pre-Installation of Intel RST Driver Using the F6 Method


1. Extract all driver files from the installation package.
2. Create a floppy\* containing the following files in the root directory:  
iaAhci.inf, iaAhci.cat,  
iaStor.inf, iaStor.cat,  
iaStor.sys, and  
TxtSetup.oem.

\* Note: For Windows Windows 7\*, you can use a floppy, CD/DVD or USB.


3. During the operating system installation, after selecting the location to install Windows 7, click Load Driver to install a third party SCSI or RAID driver.



4. When prompted, insert the media (floppy, CD/DVD or USB) you created in step 2 and press Enter.



5. At this point you should be presented with a selection for one of the controllers depending on your hardware version and configuration.



6. Highlight the selection that is appropriate for the hardware in your system and press Enter.
7. Press Enter again to continue. Leave the floppy disk in the system until the next reboot as the software will need to be copied from the floppy disk again when setup is copying files.
8. Proceed with Windows 7 installation process.