


## [Product Information] Intel Rapid Storage Technology Driver

### **Q: Why can't the IRST driver be installed??**


A: If the system has only one single PCIe SSD and the default SATA mode in BIOS is set to AHCI the messages below will appear under certain occasions.

It's unnecessary to install the IRST driver because the remapping for single PCIe SSD is not mandatory and the same system performance can be delivered by the Windows Native Driver.

- For clean installation, an error message "This platform is not supported" will show up when trying to install the IRST driver.



- Using one touch installation to install all drivers/apps at once, Intel IRST driver would show “Not Installed”.



P.S. Please uninstall the IRST driver manually, if the pre-installed OS has the IRST driver installed or an error message “The Intel Rapid Storage Technology driver is missing or has not been installed properly” would show up when running Intel Rapid Storage Technology application.

