


[How To] Reset Forgotten Windows Pin

To set up Windows Hello Face Recognition and Fingerprint, a PIN will have to be set beforehand.


If the attempts to login with Windows Hello have failed more than the number of times allowed and the Windows PIN is forgotten, please refer to the following steps to reset it.

Note: This method is only applicable if the user account password can be recalled.

1. Log into Windows with the pre-added user account password prior to setting the PIN.




2. Open Windows Settings.




1



3. Go to Sign-in Options in Accounts.




4. Click on Windows Hello PIN, then "I forgot my PIN".






5. Verify the account password.



6. Set up a new PIN.



7. The new PIN will be ready for use on the next login.