How to set the static IP address on Enjoy 71?

SOP Manual

Prepared by MSI NB FAE Team | Version: 1.0 | Date: 2013/05/16

1. Open WiFi and connect to the network.



2. Keep touching the connected SSID (Hereby touching an example network NB-TAS) until the following menu appeared



3. Select the checkbox “Show advanced options”.




Settings
NB-TAS
Status
Connected
Signal strength
Excellent
Link speed
5Mbps
Security
WPA/WPA2 PSK
IP address
192.168.0.198
Password
(unchanged)
Show password
Show advanced options
Proxy settings
None
IP settings
DHCP
Cancel
Save
Security
Language & input
VeeHotspotC8
Secured with WEP
Done
Saving screenshot...
Screenshot is being saved.

4. Select “DHCP" to “Static”.



5. Directly modify the IP or the gateway addresses, and then press “save “.

