

[Troubleshooting] After installing KB4074588 (OS Build 16299.248), some USB devices and onboard devices such as a camera, keyboard, or mouse, may stop working

Affected Model: This issue affects the notebook installed with Windows 10 KB4074588.

This is a known issue addressed by Microsoft and to fix the problem, please follow the instructions below.

1. If the laptop has a working input device such as a WiFi mouse or touchpad, and network connection is available.

Please download and install the hotfix KB4090913. The update can be automatically downloaded and installed from Windows Update. Or the stand-alone package can be downloaded from the link below. https://support.microsoft.com/help/4090913


To learn more about the installation metheods of the stand-alone package, please refer to the method 2 in the FAQ article below. https://www.msi.com/faq/notebook-2410

2. If the laptop has no working inpout deivce or a network connection.

Please follow steps below to access Windows Recovery Environment.

- Restart system and press F3 key when you see MSI logo screen.
- At recovery screen, select Troubleshoot > Select Advanced options > Select Command Prompt. Type in the passoword for the login account if you are prompted for the regirement.





 In the command prompt window, type the command based on your Windows version.

For 64bit versions of Windows:

dism.exe /image:c:\ /remove-package /packagename:Package_for_RollupFix~31bf3856ad364e35~amd64~~16299.2 48.1.17


For 32bit versions of Windows:

Note 1: If Windows is not installed on the C: drive, please change the C: in the above ccommand to the correct drive letter.

Note 2: Please be aware there is a space between "image:c:\" and "/remove-package". Ther is also another space between "/remove-package and "/packagename:"

• Close the command prompt and you will be back to recovery screen. Select **Continue** to exit and continue to Windows 10.





 We highly suggest user to install Windows Update KB4090913 after booting into Windows 10. The update can be automatically downloaded and installed from Windows Update. Or the stand-alone package can be downloaded from the link below.

https://support.microsoft.com/help/4090913

To learn more about the installation methods of the stand-alone package, please refer to the method 2 in the FAQ article below.

https://www.msi.com/faq/notebook-2410