



How to boot to BIOS in Windows 8.1

Step 1 – Open Settings App



Press “**Windows**” Key.
Then search “**PC Settings**”
App to entry “**Update and recovery**” application.



Step 2 – Select Update & Recovery



Select “**Update & Recovery**”



Personalize



View recently used settings

Step 3 – Advanced startup



Press “**Recovery**” and then “**Restart Now**” in Advanced startup.



Refresh your PC without affecting your files

If your PC isn't running well, you can refresh it without losing your photos, music, videos, and other personal files.

Get started

Remove everything and reinstall Windows

If you want to recycle your PC or start over completely, you can reset it to its factory settings.

Get started

Advanced startup


Start up from a device or disc (such as a USB drive or DVD), change Windows startup settings, or restore Windows from a system image. This will restart your PC.

Restart now


Step 4 – Troubleshooting mode



1. After restart, please select “**Troubleshoot**”



2. Then press “**Advanced**”



3. Finally, press “**UEFI Firmware Settings**”



4. System will restart then boot up to BIOS directly.

**Thanks for
your attention**

msi[™]